

















-  Plug and play hardware solution - no need for a PC
-  Plug and play Hardware-Lösung - Es wird kein PC benötigt
-  Soluzione hardware plug and play - nessun bisogno di PC
-  Compatible avec Plug & Play - Pas besoin d'un PC
-  Hardware Plug and Play - no hace falta un PC
-  Solução Plug and Play ao nível do hardware - não é necessário um PC



-  View your digital photos on a TV or monitor
-  Geniessen Sie Ihre digitalen Fotos auf Ihrem Fernseher oder Monitor
-  Visualizza le foto digitali su TV o monitor
-  Affichez vos photos numériques sur votre télévision ou un monitor
-  Visualice sus fotografías digitales en su TV o monitor
-  Visualização de fotos digitais num televisor ou monitor

## Package Contents

- Digimedia player
- Composite Video and audio cable
- S-Video cable
- Infrared remote control
- Power adaptor
- User guide

<b>Interface</b>		CF Type I/II, SD, Mini SD, SDHC, MS, MS PRO, MS Duo, MS PRO Duo, MMC, RS-MMC.
<b>Output</b>	<b>Video</b>	• Composite video (RCA jack) • S-Video (mini-Din 4 pin)
	<b>VGA</b>	D-Sub 15 pin (Female)
	<b>Audio</b>	3.5 headphone jack