MANUAL

EVOLVEO

MODEL

VERSION / DATE

Ania5, Ania 5R

III. / 17. 7. 2023





Disposal: The symbol of crossed out container on the product, in the literature or on the wrapping means that in the European Union all the electric and electronic products, atteries and accumulators must be placed into the separate salvage.

batteries and accumulators must be placed into the separate salvage after finishing their lifetime. Do not throw these products into the unsorted municipal waste.

OCE DECLARATION OF CONFORMITY

Hereby, the company Abacus Electric, s.r.o. declares that the EVOLVEO Ania 5, Ania 5R is in compliance with the requirements of the standards and regulations, relevant for the given type of device. Find the complete text of Declaration of Conformity at http://ftp.evolveo.com/ce/

Importer / Manufacturer Abacus Electric, s.r.o. Planá 2, 370 01, Czech Republic

Copyright © Abacus Electric, s.r.o. www.evolveo.com www.facebook.com/EvolveoCZ

All rights reserved.

Design and specification may be changed without prior notice

Feature

- With metal & plastic surface
- 2 USB ports
- With 5 ajustable angles
- With 4*70mm /1*125mm
- Compatiable for 9-15.6" laptop

Technical information

- Fan Speed: 2500+-10% RPM
- Fan Noise: 20dB
- Dimensions: 365*297*30mm
- · Weight: 800g


Package Contents

- 1 Laptop stand
- 1 USB cable






How to use ...



- 1 is fan indicator.
- 2 is gear indicator.
- 3 is for increasing the fans speed
- 4 is for decreasing the fans speed
- 5 is on/off button & mode selection



1. Press the on/off button to start or shut the cooler.



2. Press +/- to increase or decrease the fans speed



- 3. Press the on/off button for 1.5 seconds change the mode of the cooler.
- 1) Press once ,three fans working in a shape of triangle.
- 2) Long press once ,four small fans working
- long press twice ,one big fan working, four small fans stok working.