

# BIOS Release Notes

## TITLE

**SUBJECT:** MZ33-DC0 BIOS Release Notes version F07a  
**System:** MZ33-DC0-000,MZ33-DC1-000,R163-Z30-AAB1-000,  
R163-Z30-AAG1-000,R163-Z30-AAB2-000,R163-Z30-AAG2-000,  
R163-Z32-AAB1-000,R163-Z32-AAG1-000,R163-Z32-AAC1-000,  
R163-Z32-AAH1-000,R163-Z32-AAC2-000,R163-Z32-AAH2-000,  
E163-Z30-AAB1-000,E163-Z30-AAG1-000,R263-Z30-AAC1-000,  
R263-Z30-AAH1-000,R263-Z30-AAC2-000,R263-Z30-AAH2-000,  
R263-Z32-AAC1-000,R263-Z32-AAD1-000,R263-Z32-AAH1-000,  
R263-Z32-AAV1-000,E263-Z30-AAD1-000,E263-Z30-AAV1-000,  
R163-Z35-AAC1-000,R163-Z35-AAH1-000,R263-Z34-AAC1-000,  
R263-Z34-AAH1-000

## About This Release

**Build Date:** 2023/03/21  
**BIOS Checksum:** 0xC0023FB0 (32M)  
**Release Owner:** Candy.Wu

## BIOS Components/Contents

**Processor stepping(s) supported:** AMD Genoa Processors  
**System hardware configurations supported:** MZ33-DC0-000, MZ33-DC1-000  
**PCB Version:**  
**Microcode updates versions:**

CPUID	Family	Microcode Update ID
Genoa B0	Family 19h Model 10-1Fh	0x0A101020
Genoa B1	Family 19h Model 10-1Fh	0x0A101116
Bergamo A0	Family 19h Model 10-1Fh	0x0AA00009
Bergamo A1	Family 19h Model 10-1Fh	0x0AA00107
Bergamo A2	Family 19h Model 10-1Fh	0x0AA00203

**IPMI support:**  
**AMI Kernel version:** 5.27\_GenoaCrb\_0ACQT018  
**AGESA PI version:** GenoaPI 1.0.0.5  
**OPROM version:**

OPROM	Version
AST2600	1.12.00

## Installation Notes

**IMPORTANT NOTES:**

## BIOS Release Notes

1. Please extract the MZ33-DC0\_F07a.zip to a bootable diskette that use FAT/FAT32 format

### BIOS UPDATE INSTRUCTIONS FOR EFI Shell:

1. Insert USB flash drive to system for BIOS upgrade.
2. Power on system and boot to Build-In Shell.
3. Enter your USB filesystem, like "fs0:" or "fsx:", "x" is your USB filesystem number
4. Execute F.nsh for bios update
5. After bios flash finish, system must Power-Off to have the changes take effect.

### BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell.
3. Enter \Tool\Win32 and execute f.bat for Windows 32bit.  
Or  
Enter \Tool\Win64 and execute f.bat for Windows 64bit.
4. After bios flash finish, system must Power-Off to have the changes take effect.

### BIOS UPDATE FOR Easy BIOS Refresh:

1. The system supports remotely update BIOS if BMC existent.
2. Please download the Easy BIOS Refresh User Guide from Gigabyte website, target system support page.

### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press <DEL> during POST
2. The bios version shows on the first main page

## Known Issues/Workarounds

### Issues fixed in this version

#### F07a

1. Updated Inventory v26.
2. Added R163-Z35-AAC1-000, R163-Z35-AAH1-000, R263-Z34-AAC1-000, R263-Z34-AAH1-000 systems support.

---

#### F06

1. Updated AGESA 1.0.0.5.
2. Fixed SATA incorrect issue on WebUI page.

---

#### F05

1. Added system R163-Z30-AAG1-000, R163-Z30-AAG2-000, R163-Z32-AAG1-000, R163-Z32-AAH1-000, R163-Z32-AAH2-000, E163-Z30-AAG1-000, R263-Z30-AAH1-000, R263-Z30-AAH2-000, R263-Z32-AAD1-000, R263-Z32-AAV1-000, E263-Z30-AAV1-000 support.
-

## BIOS Release Notes

F04

1. fixed sata hot plug function.
- 

F03

1. Fine tune memory slot naming.
- 

F02

1. Update AGESA 1.0.0.2.
  2. Update Microcode.
  3. Support Bergamo CPU.
- 

F01

1. First release.
-